


Ronix[®]

Premium Quality

PNEUMATIC JACK 22T, 35T RH-4949, RH-4950



www.ronix.ir






TECHNICAL SPECIFICATION

Model	RH-4949	RH-4950
Load Capacity	22000Kg (22Ton)	35000 Kg(35Ton)
Maximum Height	430mm	490mm
Minimum Height	215mm	245mm
Lifting Height	215mm	245mm
Dimensions	555×315×250mm	555×315×250mm
Material	Q235	Q235
Wheel Material	Rubber	Rubber
Wheel Dimensions	φ200×49mm	φ200×49mm
Net Weight	45Kg	46Kg
Gross Weight	47Kg	48Kg
Include	No accessories	No accessories

PART LIST



Warning!

Read carefully and understand all **ASSEMBLY AND OPERATION INSTRUCTIONS** before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

OWNER / USER RESPONSIBILITY

DO NOT OPERATE OR REPAIR THIS PRODUCT WITHOUT READING THIS MANUAL. Read and follow the safety instructions. Keep Instructions readily available for operators. Make certain all operators are properly trained and understand how to safely and correctly operate the product. By proceeding you agree that you fully understand and comprehend the

full contents of this manual. Failure to operate this product as intended may cause injury or death. The manufacturer is not responsible for any damages or injury caused by improper use or neglect. Allow product operation only with all parts in place and operating safely. Use only genuine replacement parts. Service and maintain the product only with authorized or approved replacement parts; negligence will make the product unsafe for use and will void the warranty. Carefully inspect the product on a regular basis and perform all maintenance as required. Store these instructions in a protected dry location. Keep all decals on the product clean and visible. Do not modify and/or use for any application other than that for which this product was designed. If you have any questions relative to a particular application, DO NOT use the product until you have first contacted the distributor or manufacturer to determine if it can or should be performed on the product.

These pneumatic heavy-duty Air/Hydraulic Quick Lift Service Jack has a powerful air motor to lift heavy loads. A quick lift system allows the lifting ram to come in contact with the load faster. The compact design easily fits between dual tandem axles. Ideal for lifting axles, farm vehicles, heavy duty machinery, industrial equipment and more.

Ensure that the air source can dedicate 100-175W to each jack operated. A minimum of 110 psi air pressure is required or raise rated capacity load.

■ GENERAL SAFETY RULES

- Do not modify the Jack in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the Jack was designed.
- Always check of damaged or worn-out parts before using the Jack. Broken parts will affect the Jack operation. Replace or repair damaged or worn parts immediately.
- Store idle Jack. When Jack is not in use, store it in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re-use.

- Not for use by children or people with reduced mental capacity.
- Do not use under the influence of drugs or alcohol.
- Ensure children and other bystanders are kept at a safe distance when using product.

■INSPECTION

- Inspect the jack carefully before each use. Ensure the jack is not damaged, excessively worn, or missing parts.
- Do not use the jack unless it is properly lubricated.
- Using a jack that is not in good clean working condition or properly lubricated may cause serious injury.
- Inspect the work area before each use. Make sure it is free and clear of any potential hazards.

■DO NOT OPERATE OR REPAIR THIS EQUIPMENT WITHOUT READING THIS MANUAL.

To maintain the Service Jack and user safety, the responsibility of the owner is to read and follow these instructions.

- Inspect the service jack for proper operation and function.
- Keep instructions readily available for equipment operators.
- Make certain all equipment operators are properly trained; understand how to safely and correctly operate the unit.
- Allow unit operation only with all parts in place and operating properly.
- Use only genuine replacement parts.
- Service and maintain the unit only with authorized or approved replacement parts; negligence will make the jack unsafe for use and void the warranty.
- Carefully inspect the unit on a regular basis and perform all maintenance as required.
- Store these instructions in the handle of your jack.
- Keep all decals on the unit clean and visible.

■ SAFETY

Always follow safety precautions when installing and operating this jack. Keep all decals on the unit clean and visible. Before proceeding ensure that you fully understand and comprehend the full contents of this manual. Failure to operate this equipment as directed may cause injury or death. The distributor is not responsible for any damages or injury caused by improper use or neglect.



■ THIS IS A LIFTING DEVICE ONLY!

- This jack is designed only for lifting part of the total vehicle.
- Do not move or dolly the vehicle while on the jack.
- The vehicle must be supported after lifting immediately by appropriately rated jack stands.
- NEVER go under a vehicle that is not supported with appropriately rated jacks stands.
- Use wheel chocks or other blocking device on opposing wheels before using jack stands.

Warning!

Always use Jack Stands!

- DO NOT USE wood blocks or any other non-approved load sustaining devices. The manufacturer only warrants loads to be sustained by jack stands that meet current ASME standards.
- DO NOT USE wood blocks or any other non-approved lifting devices for a means of lifting with the jack and or load being raised. Failure to heed these warnings may cause injury or death.

SAFETY MARKINGS



Warning!

- 1- Study, understand, and follow all instructions before operating this device.
- 2- Do not exceed rated capacity.
- 3- Use only on hard, level surfaces, with less than 3 degrees of slope.
- 4- Lifting device only. Immediately after lifting, support the vehicle with appropriate means.
- 5- Do not move or dolly the vehicle while on the jack.
- 6- Lift only on areas of the vehicle as specified by the vehicle manufacturer.
- 7- No alterations shall be made to this product.
- 8- Only attachments and/or adapters supplied by the manufacturer shall be used.
- 9- Do not get under or allow anyone under the vehicle until it has been supported by jack stands.
- 10- Center load on saddle prior to lifting.
- 11- Use wheel chocks or other blocking device on opposing wheels before using jack.
- 12- Never use on a lawn mower or lawn tractor.
- 13- Do not use this jack for any use other than the manufacturer specified usage.
- 14- Do not rock the vehicle while working on or around equipment.
- 15- The following are not recommended for supporting on this equipment: Foundations, Homes, Mobile Homes, Trailers, RV's, Campers, nor Fifth Wheels, etc...
- 16- Failure to heed these markings may result in personal injury and/or property damage.

■ GENERAL SAFETY INSTRUCTIONS

Position the Jack

Position the jack to only lift on the areas of the vehicle as specified by the vehicle manufacturer.

Always Use Jack Stands

After lifting the vehicle always support the load with appropriately rated vehicle Jacks stands before working on the vehicle.

- Do Not Overload Jack
- Do not overload this jack beyond its rated capacity. Overloading this jack beyond its rated capacity can cause damage to or failure of the jack.

Always Use on Hard Level Surfaces

This jack is designed only for use on hard level surfaces capable of sustaining the load. Use on unstable or other possible loss of load.

■ Chock and Block (Stabilize)

Apply parking brake in vehicle before operating jack.

A chock is a wedge for steadying an object and holding it motionless, or for preventing the movement of a wheel Chock the wheel opposite the end being lifted.

When you block a load, you secure and support a load that is being lifted. The block(s) or stabilizer(s) should have a weight capacity that is greater than the weight of the load which is being lifted.

- Center Load on Jack Saddle
- Center load on jack saddle before lifting vehicle.
- Off center loads and loads lifted when the jack is not level can cause loss of load or damage to the jack.

Do not raise or lower the vehicle unless tools, materials and people are clear.

When the lift is being lowered, make sure everyone is standing at least six feet away. Be sure there are no tools or equipment left under or around the jack before lowering.

Always lower the jack slowly.

■ DO NOT USE THE JACK TO SUPPORT OR STABILIZE A LOAD.

Using the jack to support or stabilize a load may result in unexpected movement and result in serious injury, being crushed and death. Always securely chock and block (stabilize) the load to be lifted. Never place

any part of the body under a raised load without properly chocking and supporting the load.

Never use the jack on curved or tubular vehicle

Bumpers, this will result in the vehicle slipping off the jack and falling, causing serious injury or death. Use a bumper lift to lift most vehicles with curved bumpers or plastic bumpers.

Wear ANSI-approved safety glasses and heavy duty work gloves during use.

- Do not adjust the safety valve.
- Do not move or dolly vehicle while jack is in use.

Stay alert. Use caution and common sense when operating jack. Do not use a jack when tired, incoherent, dizzy, under the use of drugs or alcohol.

■ **Training**

Read this manual before use. Do not allow anyone who has not read this manual, and/or does not understand the requirements, to use the jack.

■ **Spectators**

Do not allow bystanders around the jack or under the load supported only by the jack.

- Do not allow anyone in the vehicle while the jack is in use. Keep all bystanders away from vehicle when in use.

■ **Inspection**

Inspect the jack carefully before each use. Ensure the jack is not damaged, excessively worn, or missing parts.

- Do not use the jack unless it is properly lubricated.
- Using a jack that is not in good clean working condition or properly lubricated may cause serious injury.

■Additional Notes:

Save the receipt, warranty and these instructions.


Do not modify the jack in any way. Unauthorized modification may impair the function and/or safety and could affect the life of the equipment. There are specific applications for which the jack was designed.

Always check for damaged or worn-out parts before using the jack. Broken parts will affect the equipment operation. Replace or repair damaged or worn parts immediately.

When jack is not in use, store it in a secure place out of the reach of children. Inspect it for good working condition prior to storage and before re use.

ASSEMBLY

1- Familiarize yourself with the jack.




2- Refer to picture when performing this step. Take off the screw located on handle piece 1; Attach handle pieces 1 and 2 making sure to align the holes on both sections. Reinsert the screw and tighten. Check to that handle is in perfect alignment with internal lowering valve mechanism. (Handle lowering mechanism must be in perfect alignment or release


mechanism will not work.)

3- Attach handle position release rod.


4- Check movement of both Pieces before next step.



5- Insert the handle (37) into handle sleeve (45) and affix the handle (37) using bolt (46).



6- Carefully place the adapter plate (40) onto the handle (37) with U-bolts (44), washer (43), lock washer (42) and nut (41). Place extension adapters on the plate and secure with spring clips (39).



! Warning!

Do not lift or carry jack by handle. Handle could dislodge and jack may fall, resulting in possible injury or property damage.


SYSTEM AIR PURGE PROCEDURE

! IMPORTANT: BEFORE FIRST USE


Perform the following Air Purge Procedure to remove any air that may have been introduced into the hydraulic system as a result of product shipment and handling. This step is to be completed without any weight on the jack.

All numbers in parenthesis (26) refer to the index number from the parts breakdown.


1- Connect air supply inlet to air source.




2- Close the release valve by turning the handle knob clockwise until firm resistance is felt.




3- When the saddle reaches Max. Lift Height, then turn the handle knob counter clockwise.



4- When the saddle reaches Min. Lift Height, with a flat blade screwdriver, push the oil fill plug slightly to the side to purge trapped air from system.



5- Close the release valve by turning the handle knob clockwise until firm resistance is felt.




6- Jack is now ready for use. Check for proper pump action.

BEFORE USE

1- Before using this product, read the owner's manual completely and familiarize yourself thoroughly with the product and the hazards associated with its improper use.


2- Perform the air purge procedure. (See previous instructions for system purge procedure.)

3- Pour a teaspoon of good quality, air tool lubricant into the air supply inlet of the lift control valve. (See illustration) Connect to air supply and operate for 3 seconds to evenly distribute lubricant.



4- Check and that the pump operates smoothly before putting into service.

5- This product is fitting use standard 1/4" NPT air fitting. If changing the fitting is required, install a 1/4" NPT fitting of your choice, ensure that thread tape or compound is used to seal connection.




6- Inspect before each use. Do not use if bent, broken or cracked components are noted.


OPERATION

■ RAISING THE JACK


- 1- Block the vehicle's wheels for lifting stability. Secure the load to prevent inadvertent shifting and movement.
- 2- Position the jack near desired lift point.
- 3- Set the Parking Brake in the vehicle.
- 4- Refer to the vehicle manufacturer owner's manual to locate approved lifting points on the vehicle. Position the jack so that the saddle is centered and will contact the load lifting point firmly.
- 5- Assemble the handle, ensure that spring clips align with slots.
- 6- Close the release valve by turning it clockwise until it is firmly closed.



7- Connect air source to the air supply inlet (26).




8- Close the release valve by turning the handle knob clockwise until firm resistance is felt.



9- Before raising the vehicle double check and verify the saddle is centered and also has full contact with the lifting point.

10- Squeeze air trigger to lift until saddle contact's load. (To stop air operation, simply release the grip on the lift control valve.) Continue to pump the jack to lift the vehicle to the desired height.



11- After lifting, support the load with appropriately rated vehicle support stands before working on the vehicle.




CAUTION:


NEVER WIRE, CLAMP OR OTHERWISE DISABLE THE LIFT CONTROL VALVE TO FUNCTION BY ANY MEANS OTHER THAN BY USING THE OPERATOR'S HAND. USE THE HANDLE PROVIDED WITH THIS PRODUCT OR AN AUTHORIZED REPLACEMENT HANDLE TO ENSURE PROPER RELEASE VALVE OPERATION. DO NOT USE EXTENSIONS ON THE AIR HOSE OR ON THE OPERATING HANDLE

■ LOWERING THE JACK

1. Raise load high enough to allow clearance for the jack stands to be removed, then carefully remove jack stands.
2. Remove support stands.
3. Grasp the handle firmly with both hands. Securely hold on to the jack handle so your hands do not slip and ensure the release valve does not rapidly lower.
4. Carefully open the Release Valve by slowly turning the handle counterclockwise. (Do not allow bystanders around the jack or under the load when lowering the jack.



5. After removing jack from under the load, push ram and handle sleeve down to reduce exposure to rust and contamination.



! WARNING:

USE EXTREME CAUTION WHEN LOWERING THE JACK. THE JACK HANDLE MAY TURN RAPIDLY. OPENING THE RELEASE VALVE TOO FAST CAN CAUSE THE JACK TO LOWER RAPIDLY. FAILURE TO HEED THESE WARNINGS COULD CAUSE SERIOUS INJURY OR DEATH.

■ MAINTENANCE INSTRUCTIONS

If you use and maintain your equipment properly, it will give you many years of service. Follow the maintenance instructions carefully to keep your equipment in good working condition. Never perform any maintenance on the equipment while it is under a load.

■ Inspection

You should inspect the product for damage, wear, broken or missing parts (e.g.: pins) and that all components function before each use. Follow lubrication and storage instructions for optimum product performance.

■ Binding

If the product binds while under a load, use equipment with equal or a larger load capacity to lower the load safely to the ground. After un-binding; clean, lubricate and test that equipment is working properly. Rusty components, dirt, or worn parts can be causes of binding. Clean and lubricate the equipment as indicated in the lubrication section. Test the equipment by lifting without a load. If the binding continues contact Customer Service.

■ **Cleaning**

If the moving parts of the equipment are obstructed, use cleaning solvent or another good degreaser to clean the equipment. Remove any existing rust, with a penetrating lubricant.

■ **Lubrication**

This equipment will not operate safely without proper lubrication. Using the equipment without proper lubrication will result in poor performance and damage to the equipment. Some parts in this equipment are not self-lubricating inspect the equipment before use and lubricate when necessary. After cleaning, lubricate the equipment using light penetrating oil, lubricating spray.

Use a good lubricant on all moving parts.

For light duty applications, use lubrication once a month.

For heavy and constant application, weekly lubrication is recommended.

- NEVER USE SANDPAPER OR ABRASIVE MATERIAL ON THESE SURFACES!

■ **Rust Prevention:**

Check rams and pump plungers on the power unit assemblies daily for any signs of rust or corrosion. Without a load, lift the equipment as high as it goes and look under and behind the lifting points. If signs of rust are visible, clean as needed.

■ **How the Long Ram Operates**

With release valve closed, an upward stroke of the long ram handle draws oil from the reservoir tank into the plunger cavity. Hydraulic pressure holds the valve closed, which keeps the oil in the plunger cavity. A downward stroke of the long ram handle releases oil into the cylinder, which forces the ram out. This raises the hydraulic ram. When the ram reaches maximum extension, oil is bypassed back into the reservoir to prevent an over extended ram stroke and possible damage to the long ram. Opening the release valve allows oil to flow back into

reservoir. This releases hydraulic pressure on the ram, which results in lowering the hydraulic ram.

■ Storing the Crane


- 1- Lower the Lifting Arm.
- 2- Place the handle in the upright position.
- 3- Store in a dry location, recommended indoors

Note: If the crane is stored outdoors, be sure to lubricate all parts before and after use to ensure the crane stays in good working condition.


Always store jack in the fully retracted position when stored in outdoor or caustic environments that can cause corrosion and/or rust.

■ TO ADD JACK OIL


- 1- Position the jack on level ground and lower the saddle.




- 2- Remove the oil plug.



- 3- Fill the oil case until oil level is just beneath the lower rim of the oil fill hole.




4- Replace oil plug.




5. Perform the Air Purge Procedure.

■ TO REPLACE JACK OIL


1- Position the jack on level ground and lower the saddle.




2- Open release valve by turning handle counter-clockwise (4 full turns).




3- Remove the oil fill plug.




4- Remove the handle.




5- Turn the jack on its side so that old oil will drain from the oil fill hole.



- 6- Fill the oil case until oil level is just beneath the lower rim.
KEEP DIRT AND OTHER MATERIAL CLEAR WHEN POURING.



- 7- Replace oil plug.



- 8- Perform the Air Purge Procedure.

■ ADDITIONAL WARNINGS:

- DO NOT USE MOTOR OIL IN THE JACK.
- ONLY USE ANTI FOAMING JACK OIL.
- ALWAYS USE A GOOD GRADE HYDRAULIC JACK OIL.
- DO NOT USE HYDRAULIC BRAKE FLUID, ALCOHOL, GLYCERINE, DETERGENT, MOTOR OIL OR DIRTY OIL.
- USE OF A NON-RECOMMENDED FLUID CAN CAUSE DAMAGE TO A JACK.
- AVOID MIXING DIFFERENT TYPES OF FLUID AND NEVER USE BRAKE FLUID, TURBINE OIL, TRANSMISSION FLUID, MOTOR OIL OR GLYCERIN. IMPROPER FLUID CAN CAUSE PREMATURE FAILURE OF THE JACK AND THE POTENTIAL FOR SUDDEN AND IMMEDIATE LOSS OF LOAD.
- DISPOSE OF HYDRAULIC FLUID IN ACCORDANCE WITH LOCAL REGULATIONS.

Additional Bottle Jack Notes:



- Periodically check the pump piston and ram for signs of rust or corrosion.

Clean as needed and wipe with an oil cloth. **NEVER USE SANDPAPER OR ABRASIVE MATERIAL ON THESE SURFACES!**

- When not in use, store the jack with pump piston and ram fully retracted.

■ LUBRICATION


Periodically check the pump piston and ram for signs of rust or corrosion. Clean as needed and wipe with an oil cloth. **NEVER USE SANDPAPER OR ABRASIVE MATERIAL ON THESE SURFACES!**



■ Storage

When not in use, store the jack with pump piston, hydraulic ram and

saddle fully retracted.




TROUBLESHOOTING

CAUSES AND SOLUTIONS	WILL NOT LIFT TO FULL EXTENSION	POOR JACK LIFTING	JACK WILL NOT LOWER	JACK WILL NOT HOLD LOAD	JACK WILL NOT LIFT LOAD
Release valve is not completely closed (Turn handle clockwise).		×		×	×
Weight Capacity Exceeded.					×
Air is in the hydraulics. Purge air from system.		×			×
Low oil level. Add oil as required.	×	×		×	×

Oil reservoir is overfilled. Drain excessive oil. Lubricate moving parts.			×		
Jack is binding or foreign obstruction			×		
Power unit malfunctioning. Replace the power unit.		×		×	×

- Safe Operating Temperature is between 40°F – 105°F (4°C - 41°C)





PNEUMATIC JACK


22T, 35T



		×			مخزن روغن بیش از اندازه روغن دارد. میزان اضافی را تخلیه نمایید. قطعات متحرک روانکاری گردد
		×			مسیر هیدرولیک گرفتگی دارد
×	×		×		معیوب بودن پمپ جک پمپ بایستی تعویض گردد.

- دمای کاربری ایمن مابین ۴ الی ۴۱ درجه سانتی گراد می باشد.

خدمات پس از فروش



توجه!

توجه داشته باشید که هیچ کدام از اجزای داخلی این ابزار احتیاج به تعمیرات اضافه یا دستکاری جهت بهینه نمودن عملکرد ندارند. بنابراین از هرگونه دستکاری یا ارائه به مراکز تعمیرات غیر مجاز اجتناب نمایید و در صورت بروز هرگونه ایراد، سریعاً با نزدیک ترین مرکز سرویس مجاز تماس حاصل نمایید تا از خدمات سریع و دقیق **رونیکس سرویس** استفاده نمایید.
برای اطلاع از عاملیت های مجاز **رونیکس سرویس** با تلفن ۰۲۱-۶۴۹۷ تماس حاصل نمایید.


■ انبار

در زمان عدم استفاده از جک، از پایین بودن رام و پیستون و کفه جک در پایین ترین نقطه اطمینان حاصل فرمایید.

عیب یابی

علت ها و راه حل ها	بصورت کامل عملیات بالا بردن صورت نخواهد گرفت.	سرعت بالا بردن بار پایین خواهد بود.	جک پایین نخواهد آمد.	جک توانایی نگه داشتن بار را نخواهد داشت.	جرثقیل توانایی بلند کردن بار را نخواهد داشت.
شیر آزادسازی جک بصورت کامل بسته نمیشود (لطفا دسته در جهت عقربه های ساعت بچرخانید)		×		×	×
تجاوز از حداکثر وزن قابل حمل جرثقیل					×
وجود هوا در سیستم هیدرولیک. لطفا هواگیری نمایید.		×			×
پایین بودن سطح روغن . روغن به مقدار مورد نیاز اضافه گردد.	×	×		×	×

۷- درپوش محفظه در محل خود قرار دهید.




۸- هواگیری سیستم هیدرولیک را انجام دهید.

⚠ هشدارهای تکمیلی:


- از روغن موتور خودرو بعنوان روغن هیدرولیک استفاده نگرده.
- از روغن ضدفوم هیدرولیک استفاده گردد.
- همیشه از روغن هیدرولیک با کیفیت استفاده نمایید.
- از روغن ترمز بعنوان روغن هیدرولیک استفاده نگرده.
- استفاده از روغن نامناسب موجب آسیب دیدن جک میگردد.
- از استفاده از مخلوط روغن های کارکرده، روغن ترمز، روغن گیربکس، روغن موتور و گلیسرین خودداری نمایید. زیرا موجب آسیب دیدن جک میگردد.
- روغن هیدرولیک تعویض شده را طبق قوانین محلی امحا نمایید.

■ روانکاری


بصورت دوره ای پمپ و رام پیستون جک را از لحاظ خوردگی و زنگ زدگی چک نمایید. در صورت نیاز با دستمال روغنی تمیز نمایید. هرگز از دستمال شنی یا زیر برای تمیز کردن استفاده ننمایید.




۳- درپوش محفظه روغن را بردارید.




۴- دسته جک را جدا نمایید.




۵- جک را روی پهلوی بچرخانید تا روغن محفظه تخلیه گردد.



۶- روغن جدید را تا لبه سوراخ محفظه روغن شارژ نمایید.
از روغنی شدن قطعات دیگر در زمان پرکردن روغن جلوگیری نمایید.




۴- درپوش محفظه روغن را ببندید.




۵- سیستم هیدرولیک را هواگیری نمایید.

■ تعویض روغن هیدرولیک جک

۱- کفه جک را در پایین ترین نقطه قرار دهید.




۲- شیر آزادکننده را در خلاف عقربه های ساعت بچرخانید. (۴ دور کامل)




■ مرحله سوم- نشیمنگاه پیستون جک
الف) نشیمنگاه برروی پیستون قرارداده شود.

■ جهت استفاده
الف) جهت بالا آمدن پیستون جک از پدال کنار پایه استفاده نمایید.
ب) جهت پایین آوردن جک شیرآزادکننده را در جهت عقربه های ساعت بچرخانید.


■ اضافه نمودن روغن به جک
۱- کفه جک را در پایین ترین نقطه قرار دهید.



۲- درپوش شارژ روغن را بردارید.



۳- روغن را تا زیر لبه سوراخ پر نمایید.



■ گریس کاری اتصالات

برخی از قطعات توسط گریس روانکاری می گردد لذا گریسکاری بایستی بصورت دوره ای صورت گیرد.

■ نحوه عملکرد جک

با بسته شدن شیر آزاد کننده و با بالا بردن دسته پمپ جک، روغن از قسمت مخزن وارد محفظه پلانجر میگردد. با افزایش فشار هیدرولیکی شیر آزاد کننده بسته شده و موجب مبهوس شدن روغن در محفظه پلانجر میگردد و همچنین با پایین آمدن دسته پمپ جک، روغن وارد محفظه سیلندر گشته و موجب حرکت نشیمنگاه بار میگردد، وقتی نشیمنگاه در بالاترین ارتفاع قرار گرفت، روغن اضافی داخل سیلندر جهت جلوگیری از خروج بیش از اندازه پیستون و آسیب دیدن پمپ وارد مخزن میگردد. و در نهایت با باز شدن شیر آزاد کننده، فشار روغن هیدرولیک کاهش یافته و به مخزن بازگشت میکند و موجب پایین آمدن نشیمنگاه جک به پایین ترین نقطه میگردد.

اقدامات لازم جهت نگهداری جرثقیل در انبار

۱- جک در پایین ترین حالت قرار داشته باشد.

۲- اهرم پمپ در بالاترین نقطه قرار داشته باشد.

۳- در محل خشک و سربسته نگه داری گردد.

⚠ توجه!

اگر جرثقیل در فضای باز نگهداری میگردد از روانکاری قطعات متحرک قبل و بعد از نگهداری جهت استفاده اطمینان حاصل فرمایید.

■ دستورالعمل سوار نمودن

جهت سهولت در فرآیند حمل و نقل، جک بصورت چند پارت جداگانه بوده و نیاز به سوار کردن قطعات است. لذا جهت سوار نمودن قطعات می توان به دو صورت، استفاده از نقشه انفجاری قطعات یا طبق دستورالعمل زیر عمل نمایید.

■ مرحله اول- شاسی

الف) ابتدا چهار چرخ جک به پایه های مربوطه توسط پیچ های همراه متصل کرده و از سفت بودن اتصالات اطمینان حاصل فرمایید.

ب) پایه ها توسط پیچ و مهره های همراه متصل گردد.

■ مرحله دوم- سیلندر

الف) پیچ های روی پایه را شل کنید و سپس سیلندر را در موقعیت صحیح روی پایه قرار داده و توسط پیچ های مربوطه سفت گردد.

■ دستورالعمل های تعمیر و نگهداری

انجام سرویس و نگهداری دوره ای جرثقیل به کاهش استهلاک قطعات و بالا رفتن طول عمر کمک می کند لذا دفترچه مربوطه را بصورت کامل و به دقت مطالعه نمایید و همچنین سرویس جک باید در حالت بی بار انجام بگیرد.

■ بازرسی

جرثقیل بایستی از لحاظ عیوب، ظاهر، شکستگی و کم شدن قطعات کوچک نظیر پین ها قبل از هر استفاده بازرسی گردد. همچنین مخزن ذخیره روغن بصورت مرتب جهت افزایش بازدهی چک گردد.

■ خم شدگی

در صورتی که جک در هنگام بلند کردن بار دچار خم شدگی شود توصیه میگردد قدرت جک برابر یا بیشتر از وزن بار تنظیم و همچنین در پایین ترین نقطه قرار داشته باشد. بعد از خم شدگی دستگاه عملیات تمیزکاری، روانکاری صورت گرفته و سپس مجدداً تست و مورد استفاده قرار بگیرد. وجود گردوغبار بر روی سطوح جک موجب استهلاک قطعات میگردد لذا طبق دستورالعمل فصل روانکاری اقدامات لازم صورت گیرد.

■ تمیز نمودن


در صورت وجود گردوغبار، گل و لای روی سطوح متحرک آنرا توسط مواد شوینده مناسب تمیز نمایید.

■ روانکاری


استفاده از روغن نامناسب موجب افزایش استهلاک، کاهش بازدهی و همچنین آسیب دیدن قطعات جک میگردد لذا به منظور بالا بردن عمر دستگاه برخی از قطعات بایستی قبل از استفاده توسط روغن مناسب با درجه نفوذپذیری بالا و همچنین اسپری روغن روانکاری گردد. از روغن با کیفیت مناسب جهت روانکاری قطعات متحرک استفاده گردد. در صورت پایین بودن ساعت کارکرد جک عملیات روانکاری ماهی یکبار صورت گیرد. در صورت استفاده روزانه از جک بصورت هفتگی عملیات روانکاری انجام گردد. هرگز از پارچه یا کاغذ آغشته به شن، گردوغبار و مواد خورنده جهت تمیز کردن استفاده نگردد.

■ اقدامات پیشگیرانه زنگ زدگی


بصورت روزانه پلانجر پمپ و همچنین پیستون جک چک گردد و بایستی فاقد هر گونه علام خوردگی و زنگ زدگی باشد. جک را در بالاترین نقطه قرار داده و سپس آنرا در آن نقطه ثابت نمایید در نتیجه بدنه پیستون جک را به دقت بررسی و عوامل زنگ زدگی را برطرف نمایید.



۸- شیر آزادکننده را در جهت عقربه های ساعت تا زمانی که مقداری احساس سفت شدن نمودید بچرخانید.



۹- بعد از آزاد کردن جک در هنگام استفاده، اجازه دهید رام پیستون بصورت کامل پایین برود تا از نشن گردوغبار روی بدنه آن جلوگیری نمایید.




هشدار!


به تمامی نکات ایمنی در زمان پایین آوردن جک توجه نمایید. دسته جک ممکن سقوط کند. از باز کردن سریع شیر آزادکننده خودداری نمایید زیرا ممکن است موجب آسیب دیدن کاربر گردد.

■ قبل از استفاده


- ۱- قبل از استفاده از این محصول، دفترچه راهنما را به دقت مطالعه نمایید.
- ۲- سیستم هیدرولیک را هواگیری نمایید. (طبق دستورالعمل گفته شده در بخش قبلی)
- ۳- اتصال نری ورودی هوای فشرده را با کمی روغن چرب نمایید و سپس شلنگ هوای فشرده را متصل نمایید و به مدت ۳ ثانیه هوای فشرده را فعال نمایید تا روغن به خوبی داخل اتصال پخش گردد.




- ۴- عملکرد پمپ را بررسی نمایید و از صحت عملکرد آن اطمینان حاصل فرمایید.
- ۵- از فیتینگ هوای فشرده با سایز ۱/۴ اینچ (ان پی تی) استاندارد استفاده کرده است. در صورت نیاز به تعویض از مدل اورجینال استفاده نمایید و همچنین آنرا از لحاظ نشتی بررسی نمایید.




- ۶- قبل از استفاده جک را از لحاظ خرابی و شکستگی بررسی نمایید.




- ۷- شلنگ هوای فشرده را به ورودی هوای فشرده شماره ۲۶ متصل نمایید.



۴- زمانی که کفه جک به پایین ترین نقطه رسید، با استفاده از یک پیچ گوشتی، به آرامی درپوش پرکن روغن را به فشار دهید تا هوای موجود در سیستم خارج گردد.



۵- شیر آزادکننده را در جهت عقربه های ساعت تا زمانی که مقداری احساس سفت شدن نمودید بچرخانید.



۶- جک آماده استفاده می باشد.



هشدار!


از دسته جک برای جابجایی آن استفاده نگردد. زیرا ممکن است دسته از محل خود خارج شود و جک روی زمین سقوط نماید، و در نتیجه باعث آسیب دیدن کاربر و جک میگردد.

مراحل هواگیری سیستم هیدرولیک




مهم: قبل از اولین استفاده


سیستم هیدرولیک ممکن است در زمان حمل از کارخانه هوا بگیرد بنابراین هواگیری را مطابق دستورالعمل زیر انجام نمایید. در زمان انجام هواگیری بار روی جک قرار ندهید.
۱- ورودی هوای فشرده جک را به کمپرسور متصل نمایید.




۲- شیر آزادکننده در جهت عقربه های ساعت تا زمانی که شیر مقداری زیر دستان سفت گردد.




۳- در زمانی که کفه جک به بالاترین نقطه رسید، شیررهاکننده را در خلاف عقربه های ساعت بچرخانید.



۴- دسته شماره ۳۷ را داخل سوراخ شماره ۴۵ نمایید و دسته ۳۷ را توسط پیچ محکم نمایید.



۵- صفحه آدپتور شماره ۴۰ را به دقت در روی دسته شماره ۳۷ به همراه اتصالات شماره ۴۴، و اشتر ۴۳، قفل کننده و اشتر ۴۲ و مهره ۴۱ قرار دهید. مبدل های افزایشنده را روی صفحه قرار داده و با استفاده از خارهای فنری ۳۹ آنرا متصل نمایید.



پایین آوردن جک به آرامی صورت گیرد.
از جک بعنوان ساپورت یا وسیله ایجاد تعادل استفاده نگردد.
استفاده از جک بعنوان موارد یاد شده ممکن است بعلت تکان خوردن و عدم تعادل بار موجب آسیب دیدن کاربر گردد. همیشه چرخ های آزاد توسط ترمز مهار گردد.
از جک در سطوح گروه ای استفاده نگردد.
با توجه به عدم مسطح بودن تکیه گاه کفه جک امکان تکان و لیزخوردن خودرو وجود دارد و موجب آسیب دیدن کاربر می گردد.
از عینک ایمنی در زمان استفاده در کاربردهای سنگین استفاده نمایید.
از تغییر و تنظیم شیر اطمینان خودداری فرمایید.
در زمان بودن خودرو روی جک از تکان دادن خودرو خودداری فرمایید.
در صورت احساس خستگی از استفاده از جک خودداری فرمایید.

■ آموزش

مطالعه دفترچه راهنما توسط تمامی کاربران جک الزامی می باشد.

■ تماشگر

افراد نزدیک جک حدامکان به دور از جک قرار داشته باشند.

■ نکات اضافی

در نگهداری دفترچه راهنما دقت فرمایید.
در عملکرد جک تغییرات ایجاد نگردد. در صورت خرابی دستگاه تمامی تعمیرات توسط نمایندگی صورت می گیرد.

بازرسی دوره ای بصورت مرتب صورت گیرد. و در صورت نیاز قطعات فرسوده تعویض گردد. همچنین در زمانی که از جک استفاده نمی کنید آن را در محل ایمن و دور از دسترس کودکان نگهداری نمایید.

- ۱- به تصاویر جهت انجام مراحل زیر مراجعه نمایید.
پیچ روی تیکه اول دسته را برداشته و تیکه های اول و دوم به یکدیگر متصل نموده و از هم مرکزی سوراخ ها اطمینان حاصل فرمایید. پیچ را جانمایی و محکم نمایید. از تنظیم بودن دسته با مکانیزم شیر پایین داخلی اطمینان حاصل نمایید. (مکانیزم پایین دسته باید در بهترین حالت تنظیم گردد در غیراینصورت مکانیزم شیر آزادکننده عمل نخواهد نمود.)
- ۲- دسته میله آزادکننده را متصل نمایید.
- ۳- حرکت هر دو قسمت را قبل از رفتن به مرحله بعد چک نمایید.

- ۷- از جک بعنوان بلند کردن خودروها استفاده گردد در موارد دیگر استفاده نگردد.
- ۸- از اکسسوری های مخصوص دستگاه استفاده گردد.
- ۹- بعد از جک زدن اتومبیل آنرا با خرک مهار نمایید.
- ۱۰- در زمان جک زدن محل قرار گرفتن اتومبیل روی کفه جک در مرکز قرار بگیرد.
- ۱۱- چرخ های آزاد خودرو توسط مانع جهت جلوگیری از حرکت خودرو مهار نمایید.
- ۱۲- برای دستگاه چمن زن استفاده نگردد.
- ۱۳- از جک در موارد گفته شده توسط سازنده استفاده گردد.
- ۱۴- از تکان دادن خودرو در زمان بودن جک زیر آن خودداری نمایید.
- ۱۵- از جرقیل برای خودروهای سنگین، ون های کمپ و درخانه استفاده نگردد.
- ۱۶- عدم رعایت نکات ایمنی موجب آسیب دیدن کاربر میگردد.

دستورالعمل های عمومی ایمنی

■ محل قرار گیری جک

جک را در محل های مخصوص مشخص شده سازنده خودرو قرار دهید.

■ استفاده از خرک

بعد از جک زدن خودرو از خرک جهت ثبات خودرو استفاده گردد.

■ اضافه بار

استفاده از جک جهت بلند کردن اجسام سنگین تر از ظرفیت حداکثر جک، موجب آسیب دیدن جک میگردد.

■ استفاده از جک در روی سطح مستحکم

از ثبات و استحکام سطح زیر جک در زمان استفاده از آن اطمینان حاصل فرمایید.

■ ثابت نمودن اتومبیل

از موانع جهت ثابت کردن چرخ های روی زمین اقدام نمایید زیر امکان حرکت خودرو وجود دارد.

■ قرار دادن جک در مرکز

کفه جک همیشه در محل مخصوص مشخص شده توسط سازنده خودرو قرار گرفته و از قرار گرفتن آن در مرکز اطمینان حاصل فرمایید.

■ ایمنی

در هنگام استفاده از جک نکات ایمنی داخل دفترچه راهنما به دقت مطالعه و همچنین در حفظ و نگهداری برچسب ها کوشا باشید. کاربر می بایست جهت راه اندازی و استفاده از جک به تمامی اطلاعات داخل دفترچه اشراف داشته باشد، در غیر این صورت هر گونه اقدام غیر اصولی موجب آسیب دیدن کاربر میگردد و شرکت هیچ گونه مسئولیتی در قبال آسیب های جانی را ندارد.



- جک فقط جهت عمل بلند کردن می باشد!
- جک فقط برای عمل بلند کردن اتومبیل طراحی گردیده است.
- وقتی زیر خودرو جک قرار دارد از تکان و چرخاندن آن خودداری فرمایید.
- بعد از جک زدن زیر اتومبیل از حرکت جهت ثبات اتومبیل استفاده ننمایید.
- به هیچ وجه در زمانی که اتومبیل را توسط خرک مهار نکرده اید به زیر آن جهت تعمیرات نروید.
- چرخ های عقب توسط مانع جهت جلوگیری از حرکت خودرو در زمان جک زدن مهار گردد.

! هشدار!

استفاده از چوب بجای خرک ممنوع می باشد از وسایل مورد تایید استاندارد استفاده گردد. از قرار دادن چوب مابین سینی خودرو و کفه جک خودداری فرمایید. زیرا در صورت شکستن چوب کاربر آسیب خواهد دید.

نکات ایمنی

! هشدار!

- ۱- قبل از استفاده از جک دفترچه راهنما به دقت مطالعه گردد.
- ۲- تجاوز از ظرفیت میزان بار قابل حمل توسط جک ممنوع می باشد.
- ۳- محل استقرار جک بایستی مستحکم و همچنین شیب آن کمتر از ۳ درجه باشد.
- ۴- بعد از جک زدن اتومبیل آنرا توسط خرک مهار نمایید.
- ۵- از تکان دادن اتومبیل زمانی جک زیر آن است خودداری نمایید.
- ۶- کفه جک در محل مقرر شده توسط سازنده اتومبیل قرار بگیرد.

قوانین ایمنی عمومی

ملاحظات مهم ایمنی

نکات استفاده و نگهداری جک

- از ایجاد هر گونه تغییر در عملکرد دستگاه خودداری فرمایید. زیرا هر گونه تغییر ممکن است موجب اختلال در عملکرد صحیح جک و افزایش استهلاک گردد.
- دستگاه قبل از استفاده بصورت مرتب از لحاظ خرابی و فرسودگی بررسی گردد. قطعات شکسته و معیوب بلافاصله تعویض گردد.
- شرایط نگهداری جک در انبار: در صورتی که نیاز به استفاده از جک ندارید آنرا دور از دسترس کودکان نگهداری فرمایید و همچنین قبل از استفاده مجدد تمامی قطعات از لحاظ سالم بودن چک گردد.
- دستگاه توسط کودکان استفاده نگردد.
- در صورت استفاده از دارو خواب آور از استفاده دستگاه خودداری فرمایید.
- جک دور از دسترس کودکان و محل امن قرار دهید.

■ بازرسی

- قبل از استفاده از جک دستگاه از لحاظ صحت عملکرد بررسی و در صورت فرسودگی یا خرابی تعویض گردد.
- قطعات متحرک روانکاری گردد در غیر این صورت استفاده توصیه نمی شود.
- در صورت چرب بودن نقاط بارگذاری شده ممکن است منجر به آسیب دیدن کاربر گردد.
- از استفاده دستگاه بدون مطالعه دفترچه راهنما خودداری فرمایید.
- جهت حفظ و نگهداری صحیح دستگاه، خریدار بایستی دفترچه راهنما را مطالعه نماید.
- جک جهت عملکرد صحیح بصورت دوره ای چک گردد.
- در حفظ و نگهداری دفترچه راهنما کوشا باشید.
- از آموزش تمامی کاربران جهت کار با دستگاه اطمینان حاصل نمایید.
- در صورت ناقص بودن قطعات دستگاه از استفاده آن خودداری فرمایید.
- از قطعات اورجینال و اصلی استفاده گردد.
- در صورت نیاز به تعمیر دستگاه، توسط سرویسکار مورد تایید نمایندگی صورت گیرد.
- سرویس های دوره ای بصورت مرتب صورت گیرد.
- دفترچه راهنما در دسته جک نگهداری گردد.
- تمامی لیبیل ها روی جک تمیز و واضح باشد.

■ وظایف خریدار

قبل از استفاده از دستگاه دفترچه راهنما به دقت مطالعه نمایید. کاربر بایستی به تمامی مطالب داخل دفترچه راهنما اشراف داشته باشد. دفترچه راهنمای محصول در محل امن نگهداری گردد و همچنین تمامی کاربران دفترچه راهنما را مطالعه و آموزش های لازم را کسب نمایند. در غیراینصورت استفاده نادرست از دستگاه موجب آسیب جانی کاربر میگردد و سازنده در قبال بی احتیاطی کاربر و رعایت نکردن قوانین ایمنی و عدم رعایت اصول صحیح استفاده از دستگاه هیچ مسئولیتی ندارد. خریدار بایستی از قطعات یدکی اورجینال در صورتی خرابی قطعات دستگاه استفاده نماید و همچنین جهت انجام تعمیرات دستگاه را به نزدیکترین نمایندگی تحویل دهید. دستگاه می بایست بصورت دوره ای مورد بررسی قرار بگیرد. در نگهداری دفترچه راهنما و لیبل های هشدار کوشا باشید. از ایجاد تغییر در عملکرد دستگاه خودداری فرمایید. در صورت هر گونه ابهام در مورد نحوه استفاده از دستگاه با نمایندگی جهت کسب اطلاعات تماس حاصل فرمایید.

■ قبل از استفاده

این جک جهت بلند کردن اجسام سنگین از ترکیب نیروی هوا و هیدرولیک کمک گرفته و مجهز به یک موتور هوای بسیار قوی می باشد که دستگاه را قادر میسازد در کوتاهترین زمان از پایین ترین نقطه به سطح جسم مورد نظر برسد. با توجه به استفاده از ترکیب نیروی هوا و هیدرولیک، دستگاه قادر به بلند کردن انواع خودرو، بدنه خودرو، کارهای سنگین، تجهیزات صنعتی و غیره ... می باشد. هر جک جهت استفاده به فشار هوای ۱۰۰-۱۷۵ پی اس ای نیاز دارد. فشار مینیمم ۱۱۰ پی اس ای جهت بلند کردن اجسام ضروری می باشد.

قوانین عمومی ایمنی



هشدار!

دفترچه راهنما مطالعه گردد. در غیراینصورت منجر آسیب دیدن کاربر میگردد.



توجه!


کاربران در صورت عدم آموزش از استفاده دستگاه خودداری نمایند.



هشدار!

هشدارها، اخطار و دستورالعمل های مورد بحث در این دفترچه نمی تواند تمامی خطرهای که ممکن است برای کاربر رخ دهد را نام ببرد. بنابراین تا حد امکان دفترچه راهنما توسط کاربر به دقت مطالعه گردد.

اجزاء و قطعات



⚠ هشدار!

در صورت وجود هر گونه سوال، اشکال و گم شدن قطعات قبل از عودت کالا، با نمایندگی تماس حاصل فرمایید.
کتابچه راهنما را به طور کامل مطالعه نمایید تا از شرایط ایمنی، تعمیر و نگهداری و استفاده از دستگاه آگاهی لازم را در جهت پیشگیری از بروز هر گونه آسیب فردی و دستگاه کسب نمایید.

مشخصات فنی

مدل	RH- ۴۹۴۹	RH- ۴۹۵۰
ظرفیت بارگیری	۲۲۰۰۰ کیلوگرم (۲۲ تن)	۳۵۰۰۰ کیلوگرم (۳۵ تن)
بیشینه ارتفاع	۴۳۰ میلی متر	۴۹۰ میلی متر
کمینه ارتفاع	۲۱۵ میلی متر	۲۴۵ میلی متر
ارتفاع بارگیری	۲۱۵ میلی متر	۲۴۵ میلی متر
ابعاد	۲۵۰ x ۳۱۵ x ۵۵۵ میلی متر	۲۵۰ x ۳۱۵ x ۵۵۵ میلی متر
جنس بدنه	Q235	Q235
جنس چرخ	پلاستیکی	پلاستیکی
ابعاد چرخ	۴۹ x ۲۰۰ Φ میلی متر	۴۹ x ۲۰۰ Φ میلی متر
وزن خالص	۴۵ کیلوگرم	۴۶ کیلوگرم
وزن ناخالص	۴۷ کیلوگرم	۴۸ کیلوگرم
متعلقات	ندارد	ندارد




رونیکس®

آخرین ابزاری که می‌خرید!

جک سوسماری بادی ۲۲ تن، ۳۵ تن

RH-4949, RH-4950



www.ronix.ir