



Number	Name
1	BAFFLE PLATE
2	BALL BEARING 608-2Z
3	INSULATION WASHER
4	ARMATURE
5	SOCKET HEX HEAD SCREW
6	FLAT WASHER
7	LOOP HANDLE
8	BEARING RETAINING COVER
9	BALL BEARING 6201-2Z
9	BALL BEARING 6201-2Z
10	HEAD CASE
11	TAPPING SCREW
12	LOCK PIN CAP
13	SHAFT LOCK SPRING
14	SCREW
15	SCREW
16	SHAFT LOCK PIN
17	NEEDLE BEARING HK0810
18	SHAFT RETAINING RING
19	GEAR
20	INNER RETAINING RING
21	FORNT COVER
22	SCREW
23	DUST CAP
24	SPINDLE
25	METRIC BACKING PAD
26	WOODRUFF KEY
27	BRUSH HLODER CAP (2 pcs)
28	CARBON BRUSH (2 pcs)
29	BRUSH HOLDER (2 pcs)
30	NAMEPLATE
31	STATOR
32	SCREW
33	MOROR HOUSING
34	SPEED DIAL LABEL
35	HANDLE (RIGHT)
36	CORD GUARD
37	CORD
38	STRAIN RELIEF
39	CROSS TAPPING SCREW ST4.2x16

Number	Name
40	HANDLE (LEFT)
41	DC SWITCH
42	RIVET
43	SWITCH SPRING
44	ADJUSTING SPEED SWITCH
45	LABEL
46	TAPPING SCREW
47	HEAD SHELTER
48	SPRING WASHER
49	FLAT WASHER
50	SPRING WASHER
51	SHELTER COVER
52	CAPACITOR