



RS-0001

Cordless drill driver kit 12V

| Number | Name |
|--------|----------------------------------|
| 1 | Chuck Screw |
| 2 | Key Chuck |
| 3 | Output Spindle |
| 4 | spring |
| 5 | Ball Bearing |
| 6 | Circlip |
| 7 | Big Gear |
| 8 | Needle Bearing |
| 9 | Function Knob |
| 10 | Function Plate |
| 11 | Bearing Support |
| 12 | Ball Bearing |
| 13 | Armature |
| 14 | Field |
| 15 | Plastic Brush Holder |
| 16 | Carbon Brush |
| 17 | Brush Holder Cap |
| 18 | Ball Bearing |
| 19 | Housing-L |
| 20 | Inductance 1 |
| 21 | Inductance 2 |
| 22 | L/R Knob |
| 23 | On-Off Switch |
| 24 | Capacitor |
| 25 | Cable Protector |
| 26 | Cabel |
| 27 | Housing Screw |
| 28 | Housing-R |
| 29 | Bolt |
| 30 | Handle support |
| 31a | Side Handle Anti-vibration(NUT7) |
| 31S | Side Handle Simple(NUT7) |
| 32 | Depth Gauge |
| 33 | chuck key spanner |
| 13 | Armature |
| 14 | Field |
| 19 | Housing-L |
| 20 | Inductance 1 |
| 21 | Inductance 2 |
| 23 | On-Off Switch |
| 28 | Housing-R |